


**L131562**















**L131567**



1




Güterzuglokomotive mit Schlepptender, Baureihe 56<sup>2-8</sup>, Lok-Nr. 56 338, DB, Epoche III  
 Goods train locomotive with tender, class 56<sup>2-8</sup>, Loco No. 56 338, DB, Epoch III

























L131562 > L31562 <	L131567 > L31567 <	Bezeichnung	Description	Preis- gruppe
L31562-110-1		Lokgehäuse komplett 	Loco body shell complete	16
L31562-125-1		Umlaufbleche 	Catwalks	07
L31561-132-1		Fenster-Set 	Window-set	04
L31562-139-1		Set Gehäuse-Teile Lok 	Bodyshell put up parts	07
L31562-140-1	L31567-140-1	Fahrgestell Lok komplett ohne Motor 	Loco chassis complete w/o motor	16
L31562-141-1		Set Fahrgestell-Teile 1 Lok 	Chassis part set 1 loco	05
L31561-141-2		Set Fahrgestell-Teile 2 Lok 	Chassis part set 2 loco	06
L31561-141-3		Chassis-Abdeckplatte Lok 	Chassis cover loco	06
L31562-145-1		Gestänge + Zylinderblöcke 	Linkage + cylinder blocks	11
L31562-151-1		Tenderkasten + Tenderaufsatz 	Tender body + top part	10
L31561-153-1		Tenderaufsteckteile komplett 	Tender put up parts	04
L31562-156-1	L31567-156-1	Tenderchassis komplett 	Tender chassis complete	14
L31562-157-1		Tenderchassisteile-Set 	Tender chassis put up part set	04
L31561-157-2		Lautsprecherhalterung 	Speaker mounting	03

**L131562**

**L131567**



2

L131562 > L31562 <	L131567 > L31567 <	Bezeichnung	Description	Preis- gruppe
L31561-157-3		Tender Trittstufen-Set	 Tender steps	04
L31561-166-1	L31566-166-1	Vorlaufgestell Lok komplett	 Front bogie loco complete	07
L31561-172-1		Lichtleiter + Lampen	 Light conductors + lamps	05
L31562-801-1	L31567-801-1	Platinen-Set Lok mit Kupplung	 PCB set loco with coupling	10
L31562-801-2	L31567-801-2	Platinen-Set Tender mit Kupplung	 PCB set tender with coupling	11
L31561-811-1		Radkontakte Lok komplett	 Wheel contacts loco complete	07
L31561-811-2		Radkontakte Tender komplett	 Wheel contacts tender complete	07
L31561-901-1		Kupplungseinheit Lok komplett + Feder	 Coupling unit loco complete + spring	04
L31561-901-2		Kupplungseinheit Tender komplett + Feder	 Coupling unit tender complete + spring	04
L31561-903-1		Kupplungsdeichsel vorn Lok + Feder	 Coupling shaft front loco + spring	04
L31561-903-2		Kupplungsdeichsel Tender hinten + Feder	 Coupling shaft tender rear + spring	04
L31561-910-1	L31566-910-1	Treibradsatz Lok komplett	 Driving wheel set loco complete	12
L31561-910-2	L31566-910-2	Radsatz Tender komplett	 Wheel set tender complete	08
L31561-940-1		Schrauben-Set	 Screw set	03
L31561-980-1		Motor komplett	 Motor complete	09
L31561-990-1		Getriebeteile komplett	 Gear unit complete	07
L938003		Brückenstecker 21-polig	 Jumper plug 21-pin	
	L938975	Digital Decoder	 Digital decoder	
	L938991	Mittelkontakt Schleifer	 Middle contact	
	L938997	Schleifer-Halter Typ 3	 Holder type 3	
L939385		Haftreifen	 Traction tyres	
L939870		Pufferbohlen-Steckteile-Set lang	 Buffer beam parts long	
L939871		Pufferbohlen-Steckteile-Set kurz	 Buffer beam parts short	
L939881		Puffer Set	 Buffer set	