














L131951

L131956























1

Schlepptenderlokomotive, B 3/4, Lok-Nr. 1367, SBB, Epoche IV - VI
 Steam locomotive with tender, B 3/4, Loco No. 1367, SBB, Epoch IV - VI

L131951 > L31951 <	L131956 > L31956 <	Bezeichnung	Description	Preis- gruppe
L31951-110-1		Lokgehäuse komplett 	Loco body shell complete	16
L31950-132-1		Fenster-Set 	Window-set	04
L31951-139-1		Set Gehäuse-Teile Lok 	Bodyshell put up parts loco	07
L31950-140-1	L31955-140-1	Fahrgestell Lok komplett ohne Motor 	Chassis loco complete w/o motor	16
L31950-141-1		Set Fahrgestell-Teile Lok 	Chassis part set loco	05
L31950-145-1		Gestänge und Zylinder komplett 	Linkage and cylinders complete	11
L31951-151-1		Tenderkasten komplett 	Tender body complete	10
L31951-153-1		Tenderaufsteckteile komplett 	Tender put up parts complete	04
L31951-156-1	L31956-156-1	Tender-Fahrgestell komplett 	Tender chassis complete	14
L31950-157-1		Tender-Fahrgestellteile-Set komplett 	Tender chassis put up parts complete	03
L31950-157-2		Lautsprecherhalterung 	Speaker mounting	03
L31950-166-1	L31955-166-1	Vorlaufgestell Lok komplett 	Front bogie loco complete	08

Schleppenderlokomotive, B 3/4, Lok-Nr. 1367, SBB, Epoche IV - VI
 Steam locomotive with tender, B 3/4, Loco No. 1367, SBB, Epoch IV - VI

2

L131951 > L31951 <	L131956 > L31956 <	Bezeichnung	Description	Preis- gruppe
L31950-170-1		Lichtleiter Set mit Lampen	 Light conductor set with lamps	05
L31950-801-1	L31955-801-1	Hauptplatinen-Set mit Kupplungs-schaft hinten Lok	 Main PCB set + rear coupling shaft loco	10
L31950-801-2	L31955-801-2	Hauptplatine mit Kupplungs-schaft vorne Tender	 Main PCB + front coupling shaft tender	10
L31950-811-1		Radkontakte Lok	 Wheel contacts loco	07
L31950-811-2		Radkontakte Tender	 Wheel contacts tender	07
L31950-903-1		Kupplungsdeichsel Lok vorne mit Feder	 Coupling shaft loco front with spring	04
L31950-903-2		Verbinder für Lok-Tenderkupplung	 Connecting part for loco-tender coupling	03
L31950-903-3		Kupplungsdeichsel Tender hinten mit Feder	 Coupling shaft tender rear with spring	04
L31950-910-1	L31955-910-1	Treibradsatz Lok komplett	 Wheel set loco complete	11
L31950-910-2	L31955-910-2	Vorlaufradsatz Lok komplett	 Front bogie wheel set loco complete	09
L31951-910-3	L31956-910-3	Radsatz Tender komplett	 Wheel set tender complete	08
L31950-940-1		Schrauben-Set	 Screw set	03
L31950-980-1		Motor mit Halteklammern komplett	 Motor with mounting clips complete	09
L31950-990-1		Getriebeteile komplett	 Gear unit complete	07
L938002		Brückenstecker 21-polig	 Jumper plug 21-pin	
	L938992	Mittelkontakt-Schleifer	 Middle contact	
L939385		Haftreifen	 Traction tyres	
L939870		Pufferbohlen-Steckteile-Set lang	 Buffer beam parts long	
L939871		Pufferbohlen-Steckteile-Set kurz	 Buffer beam parts short	
L939882		Puffer-Set	 Buffer set	