


L131972

L131977




1

Schlepptenderlokomotive, A 3/5-700, Lok Nr. 705, SBB, Epoche V
Tenderlocomotive Class A 3/5-700, No. 705, SBB, Epoch V

L131972 > L31972 <	L131977 > L31977 <			
L31972-110-1		Lokgehäuse komplett		Loco body shell complete
L31970-125-1		Umlaufblech		Catwalk
L31970-132-1		Fenster-Set		Windows
L31972-139-1		Set Gehäuse-Teile Lok		Bodyshell put up parts
L31972-140-1	L31977-140-1	Fahrgestell Lok ohne Motor komplett		Loco chassis w/o motor complete
L31970-141-1		Set Fahrgestell-Teile Lok		Chassis part set loco
L31970-145-1		Gestänge und Zylinder komplett		Linkage + cylinders complete
L31972-151-1		Tenderkasten komplett		Tender body complete
L31970-153-1		Tenderaufsteckteile komplett		Tender put up parts complete
L31972-156-1	L31977-156-1	Tender-Fahrgestell komplett		Tender chassis complete
L31970-157-1		Tender-Fahrgestellteile-Set		Tender chassis put up part set
L31970-157-2		Lautsprecherhalterung		Speaker mounting
L31970-166-1	L31975-166-1	Vorlaufgestell Lok komplett		Front bogie loco complete
L31972-166-2	L31977-166-2	Drehgestell Tender komplett		Tender bogie complete
L31970-170-1		Lichtleiter-Set mit Lampen		Light conductor set + lamps
L31970-801-1	L31975-801-1	Hauptplatine Lok		Main PCB loco
L31970-801-2	L31975-801-2	Hauptplatine Tender		Main PCB tender



















L131972

L131977



2

Schlepptenderlokomotive, A 3/5-700, Lok Nr. 705, SBB, Epoche V
Tenderlocomotive Class A 3/5-700, No. 705, SBB, Epoch V

L131972 > L31972 <	L131977 > L31977 <		
L31972-811-1		Radkontakte Lok	 Wheel contacts loco
L31970-811-2		Radkontakte Tender	 Wheel contacts tender
L31970-903-1		Kupplungsdeichseln Lok	 Coupling shafts loco
L31970-903-2		Kupplungsdeichseln Tender	 Coupling shafts tender
L31970-910-1	L31975-910-1	Treibradsatz Lok komplett	 Wheel set loco complete
L31970-910-2	L31975-910-2	Vorlaufradsatz Lok komplett	 Front bogie wheel set loco complete
L31972-910-3	L31977-910-3	Radsatz Tender komplett	 Wheel set tender complete
L31970-940-1		Schrauben-Set	 Screw set
L31970-980-1		Motor mit Halteklammern	 Motor + mounting clips
L31970-990-1		Getriebeteile komplett	 Gear unit complete
L938003		Brückenstecker 21-pol.	 Plug 21 pin
	L938975	Digital-Decoder	 Digital decoder
	L938991	Mittelkontakt Schleifer	 Middle contact
	L938997	Schleifer-Halter Typ 3	 Holder type 3
L939385		Haftreifen	 Rubber tires
L939870		Pufferbohlen-Steckteile-Set lang	 Buffer beam parts long
L939871		Pufferbohlen-Steckteile-Set kurz	 Buffer beam parts short
L939882		Puffer	 Buffer set